VR-7: the essentials

In an emergency

CPR

Pull either red handle at the side of the backrest. Or lift the red cover under the footboard panel and press CPR.

EMERGENCY TRENDELENBURG

Red cover under the footboard panel, or outer face of either head-end side rail. Hold the button.

Every shift

- Red CPR handles in place and clear.
- Bed at lowest height and braked when the patient is unattended.
- Side rails locked when raised: pull to check.
- Battery charging when plugged in.

Footboard panel

Press **Lock** to unlock. The panel locks itself after 60 seconds.

Weighing

Patient still, nothing touching the bed, press **Scale**. Use **Tare** before and after adding or removing equipment.

Lateral tilt

Stops at 15° unless both low-side rails are raised. Check lines and drains first.

Patient-exit detection

Zone 1: moving to the edge. Zone 2: sitting on the edge. Zone 3: leaving the bed.

Moving the bed

Unplug, hang the lead on its hook, release brakes, set steering.



Cardiac chair

Flat / CPR



Trendelenburg

This card does not replace the instructions for use (VRM-IFU-0701-EN-GB). Breakdowns: Van Roon service desk 0808 157 0614, service@vanroon.uk.

Panel messages

Message	What to do
CHECK BRAKE	Apply the brakes.
BATTERY LOW	Plug the bed in.
TILT LIMITED	Raise and lock both rails on the low side.
MOVEMENT STOPPED	Clear the obstruction under the bed, then move the other way.
EXIT ALARM	Attend the patient. Press Exit to silence.
OVERLOAD	Remove equipment from the bed.
SURFACE ALARM	See the mattress instructions.
CONTROLLER FAULT	Note the code and call the service desk.

Van Roon Medical UK Ltd, Unit 3, Tarnfield Way, Morley, Leeds LS27 0YT. 19 May 2025.